

INSTRUCTIONS FOR INSTALLATION ANTI-FLOOD BARRIER IN AUTONOMOUS MODE

1) Place the threshold profile (where needed) and mark the holes, then drill, clean and secure with the screws. (Lay the silicone at the bottom of the threshold profile before screwing it firmly).

Be careful to sew carefully in the underneath and on the edges.

2) Position the side supports (above the threshold profile where needed).

Mark the holes, then drill, clean and lay the silicone behind the brackets and fasten them with the screws.

Be careful to carefully seal all the parts in the inside and hold the bulkhead where the bulkhead will be positioned

NOTICE all the bulbs are equipped with manual pressure mechanisms for greater pressure using bolts and the supplied wrench.

RECOMMENDED

The pressure mechanisms in the supports must be positioned outside the flooding flood.

For more information, contact the support telephone number.